

FANTOM DRIVES By MicroNet

XBOX ONE STORAGE HUB USB 3.0 HUB & HARD DRIVE UPGRADE

USER MANUAL

Your Xbox One Storage Hub is formatted for your console and ready to use. Please follow the steps below.

Connecting your Xbox One Storage Hub

1. Turn off the console; Press and hold the Xbox button on your controller until the "Console Off" menu appears and select "Console Off."

2. Place your Xbox vertically. (see figure below)



3. Line up the USB attachment port first and then snap on the Xbox One Storage Hub.

4.Gently push the Xbox Storage Hub into position until you hear a click. Make sure the storage hub is flush to the console and there are no visible gaps.

5. Place your Xbox back to horizontal.



6. Turn on your Xbox One.

7. The console will detect the unit and display "Fantom-Drives - External Storage ready"

If you get this message "Try another USB port or cable. We see your external storage, but the connection is too weak to use. (0x808200d)." The Xbox One storage Hub is not attached properly to the Xbox. Retry Step 1 to 7.

Managing Storage

1. In "My Games & Apps" on your Xbox One TM console, you can view content by storage device. To do this, highlight a game or app, press the Menu button on your controller, and then select Manage game. You will then be able to move or copy content between storage devices. The built in Xbox OneTM hard drive is seen as "Internal" in the drop down menu. The hard drive of the Fantom Drives Xbox Storage Hub will be seen as the "Fantom-Drives" in the drop down.

2. To change the default game and app install location, navigate to the "Settings/ System/Manage Storage" Menu.



Thank you for purchasing the Xbox One Storage Hub. We appreciate your business! If in any way you are having trouble with your unit, please contact us directly. Our customer support staff are here to help you Monday-Friday 9AM - 4PM PST. You can call us at 1-800-800-DISK, chat with us on www.fantomdrives.com, or email us at support@fantomdrives.com

Thank you. - Fantom Drives Team